

JK REAR FENDER DELETE INSTALLATION INSTRUCTIONS

TOOLS NEEDED

- 3/16" Allen Wrench
- 10mm wrench
- 1/2" socket or Wrench
- 17/32" drill bit
- 1/4" drill bit
- Drill
- Utility Knife
- Flat head screwdriver

HARDWARE

- 26 - 5/16 X 3/4 Button Head
- 12 - 5/16 Nutsert
- 4 - 5/16 Flange Nut
- 1 - 5/16 Nutsert Tool

**Please read the mounting instructions below
carefully before attempting to install.**

Thank you for purchasing your new rear fenders from JcR Offroad! Checkout our website, www.jcroffroad.com for other great off-road products. Be sure to rate and review our product online. If you have any questions or are missing parts, please don't hesitate to call us at 269-353-1184!

It is always best to trial install before painting/finishing to ensure proper fit. If using a bed liner type product, you may need to use a drill or file to open holes or openings to the proper size. Be sure to keep any and all paint or bed liner products away from all threads.

- 1** Using the 1/4" drill bit, drill out the plastic rivets holding the rear fender to the inner fender lining.



- 2** Using a flat head screwdriver, remove the 2 clips attaching the inner fender liner.

- 3** You can now remove the rear fender. Wipe down and clean the body. Your rear fender should look roughly like this.



4 With the rear fender off, you can now mark and trim the inner fender liner. We recommend using the body line as your guide.

5 Using the 17/32" drill bit, drill out the holes marked below.



6 Install the Nutserts into the holes that you just drilled. Using the provided nutsert tool, install the nutsert into the two holes you just drilled. We recommend you apply some RTV on the nutserts before installing them into the holes to lessen the chance of rust. For the nutsert tool use a 1/2 inch socket and a 11/16 end wrench. We recommend using an impact for speed, but it can be done with just hand tools. Go until the nutsert is fully crushed at 40 foot pounds.



- 7** Place the body mounts and use the 5/16 bolts to attach. Three bolts on each mount will go into the nutserts and one will use a flange nut.



- 8** Place the outer plate over the body mounts. Use the rest of the 5/15 button heads to loosely mount it. Once all bolts are started, tighten down.



- 9** Now its time to take those new fenders out and show them off at the mall!

JKRX-D - REAR FENDER DELETES - JK WRANGLER

Item Code Legend

EX: JKRX-D-PC

-PC : Powder-coated

-BARE : Bare Metal



Additional Parts



Front Inner



Rear Inner

Bolt Pack:

JKRX-D-BP:

- 26 - 5/16 X 3/4 Button Head
- 12 - 5/16 Nutsert
- 4 - 5/16 Flange Nut
- 1 - 5/16 Nutsert Tool