



# JK TRANSFER CASE SKID INSTALLATION INSTRUCTIONS

## TOOLS NEEDED

- 7/32" allen
- 9/16" wrench
- 9/16" socket
- 1/2" drill bit

## HARDWARE

- 1/2" x 1" bolt (1)
- 1/2" washer (1)

**Please read the mounting instructions below  
carefully before attempting to install.**

Thank you for purchasing your new skid from JcR Offroad! Check out our website, [www.jcroffroad.com](http://www.jcroffroad.com) for more deals and other great off-road products. Be sure to rate and review our product online. If you have any questions or are missing parts, please don't hesitate to call us at 269-353-1184!

It is always best to trial install before painting/finishing to ensure proper fit. If we need to make a repair/modification will not be responsible for finishes

**1** Remove factory t-case skid [if equipped].

**2** Reusing stock hardware, attach the skid with the frame side bolt and rear gas tank mount bolt.

**3** If installing engine skid, the three crossmember bolts are shared, so leave them out for the time being and proceed to Engine Skid install. Otherwise, follow step 4.

**4** If not installing engine skid, then thread in the three crossmember bolts and tighten them down; also tighten the first two bolts at this time.

**5** On driver side frame, a 1/2" hole will need to be drilled. Insert frame nut guide (supplied) into side hole of frame, install 1/2" bolt, and tighten.

