



# JL CLASSIC SLIDER INSTALLATION INSTRUCTIONS

## TOOLS NEEDED

- 10mm socket
- 13mm socket
- 18mm socket
- 3/16 Hex

## HARDWARE

- 5/16 - 18 X 3/4 BUTTON HEAD BOLT qty12
- 5/16 - 18 FLANGE NUT qty 12

**Please read the mounting instructions below  
carefully before attempting to install.**

Thank you for purchasing your new JL Classic Sliders from JcrOffroad! Checkout our website, [www.jcroffroad.com](http://www.jcroffroad.com) for other great off-road products. Be sure to rate and review our product online. If you have any questions or are missing parts, please don't hesitate to call us at 269-353-1184!

- 1** Remove the 6 bolts that go through the bottom of the tub. There are 3 on each side. Use a 13mm socket to remove the bolts. Next, remove the 12 side bolts that go through the pinch seam. There are 6 on each side. Use a 10mm socket to remove these. Hold the slider in place after removing the bolts to keep it from falling then remove the slider from the vehicle.



- 2** Remove the 3 body mount bolts on each side with an 18mm socket. These bolts are long and may require you to pull down on them.



- 3** Begin to install your new JCR Slider. Use a jack to hold the slider in place as you insert the bolts. Once the holes are lined up with the pinch seam, loosely place the bolts through the holes. Once you get the bolts place in the pinch seam, you can then insert the 3 body mount bolts loosely.

**A**



**B**



**C**



- 4** Next, remove the jack and begin tightening the bolts. Start with the 6 bolts that go through the pinch seam. Use a 3/16 Hex and a 13mm end wrench to tighten the pinch seam bolts. Next, tighten down the 3 body mount bolts with the 18mm socket.



Go back and check to make sure all bolts are tight.

Enjoy your new JL Classic Sliders!