



XJ Super Slider Installation Guide

Parts List:

- 2 - *Super Sliders*
- 16 – 3/8" self-threading bolts
- 10 – 5/16" bolts
- 10 – 5/16" nuts
- 20 – 5/16" washers

Tools Needed:

- Tape measure
- Floor jack
- 5/16" drill bit
- Electric drill
- Marking pen, or awl
- 3/8" drive ratchet
- 9/16" socket (3/8" drive)
- 1/4" drive ratchet
- 1/2" socket (1/4" drive)
- 1/2" box-end wrench

With problems, questions, or concerns; please contact us at:

(269)353-1184 or
info@jcroffroad.com



1. Please take the time now to paint your sliders with the coating of your choice. (It will be much easier off the vehicle.)
2. Place one *Super Slider* on the floor jack (use a block of wood if your worried about marring the sliders finish)



3. Jack the slider into it's general position under the rocker of the Jeep.
4. With your tape measure, center the slider between the front and rear fender flares.

5. Use two of the 5/16" nuts included in the hardware kit on the front and rear of the slider for proper spacing under the XJ's rockers.
6. Once the sliders are centered on the Jeep, jack the slider tightly against the spacers and XJ rockers.



7. Be sure and press the mounting plate up tightly against both the uni-frame rail and the floor of the Jeep.
8. Double check the fit of the sliders and with the 5/16" drill bit and drill start drilling the pilot holes for the self threading mounting bolts *



9. Using the 9/16" socket and ratchet, install the bottom two self-threading bolts. Do this on both front and rear plates of the sliders.

Only thread these bolts in half-way for now.



10. Using your marking pen or awl, mark the holes that need to be drilled on the pinch seam. (Mark the outside surface of the pinch seam.)
11. Let the floor jack down and the sliders should drop enough to allow you to drill the holes you just marked with the 5/16" bit and drill *

12. Once the 5 pinch seam holes are drilled, use your floor jack to jack the sliders back into position.
13. Now take the 5/16" bolts, washers, and nuts included in the kit and bolt the pinch seam support, to the pinch seam.
14. Install the rest of the self-treading bolts on the mounting plates and tighten them all down.



15. Once all bolts are tight your installation on this side is complete, please follow the same steps on the other side.

*Please note, you may want to spray a rust preventative or undercoating on the holes after you drill them to protect the bare metal.

Enjoy your new *Super Sliders!*