

XJ REAR WINDOW MOLLE PANEL INSTALLATION

TOOLS NEEDED

- T-50 Torx
- Phillips Head Screwdriver
- 3/16" Allen
- 8mm socket
- Drill (96 and down)

HARDWARE

- 2 1/2" Sheet Metal Screw qty. 1
- 5/16-18 1" Button Head qty. 4
- 5/16"-18 Flange Nut qty. 4

**Please read the mounting instructions below
carefully before attempting to install.**

Thank you for purchasing your MOLLE panel from JcR Offroad!
Checkout our website, www.jcroffroad.com for other great off-road products. Be sure to rate and review our product online. If you have any questions or are missing parts, please don't hesitate to call us at 269-353-1184!

- 1** Loosen the seat back bracket and remove the rear two bolts. Place the front MOLLE panel bracket behind the seat back bracket and reinstall. Leave it loose until the panel is fully installed.



- 2** Remove the upper seatbelt bolt using a T-50 Torx. Place the upper MOLLE panel bracket over the seatbelt bracket as shown. Reinstall the bolt & brackets, ensuring that the tab on the seatbelt bracket is up inside the roof.



- 3** Put the MOLLE panel in place, behind the seatbelt and in front of the mounting brackets. Loosely bolt it in place.



- 4** 97 +: Remove the interior panel screw as shown and reinstall through the rear MOLLE panel bracket using the supplied screw. The bend will go towards the MOLLE panel.



- 96 -: You will not have this interior screw. Install the rear bracket on the MOLLE panel and use the rear hole as a guide. Drill through the interior plastic and the sheet metal behind it. Install using the provided sheet metal screw.



5 Align the panel in the window opening, tighten all of the hardware down, and that's it! Enjoy your new MOLLE panel!

