



FRONT LOWER CONTROL ARM SKIDS INSTALLATION INSTRUCTIONS

TOOLS NEEDED

- Welder
- Sander or Grinder with wire wheel

OPTIONAL TOOLS

HARDWARE

- NONE

Please read the mounting instructions below carefully before attempting to install.

Thank you for purchasing your new Truss Kit from JcR Offroad! Checkout our website, www.jcroffroad.com for other great off-road products. Be sure to rate and review our product online. If you have any questions or are missing parts, please don't hesitate to call us at 269-353-1184 x20!

You should first test the fit of your JcrOffroad Truss before welding this product.

1 Start with one side and drop the lower control arm from the mounting bracket and let it hang out of the way. Clean the edges of the lower control arm brackets and the axle tube just above the brackets, down to the bare metal.

2 Tack weld the skid in place, then proceed to weld the skid to the lower control arm bracket and the front of the axle tube as shown.



3 Once the skid is fully welded and has cooled, cover any bare steel with your choice of coatings.

4 Install the lower control arm back into the mounting bracket. Repeat on the other side.

5 Thats it, now hit the trails knowing that your lower control arms are protected!

JKF-LCAS & JPF-LCAS - FRONT LOWER CONTROL ARM SKIDS

Item Code Legend
EX: JKF-LCAS
JK : JK Wrangler
JP : Non JK



JKF-LCAS x2
May differ from photo

Bolt Pack:
NONE