



# XJ CENTER CONSOLE BRACKET INSTALLATION INSTRUCTIONS

## TOOLS NEEDED

- Phillips screwdriver

## OPTIONAL TOOLS

- Flat head screwdriver

## HARDWARE

- Re-use factory hardware

**Please read the mounting instructions below  
carefully before attempting to install.**

Thank you for purchasing your new console bracket from JcR Offroad! Checkout our website, [www.jcroffroad.com](http://www.jcroffroad.com) for other great off-road products. Be sure to rate and review our product online. If you have any questions or are missing parts, please don't hesitate to call us at 269-353-1184 x20!

It is always best to trial install before painting/finishing to ensure proper fit. If using a bed liner type product, you may need to use a drill or file to open holes or openings to the proper size. Be sure to keep any and all paint or bed liner products away from all threads.

- 1 With your center console storage empty, remove the two Phillips head screws from the bottom of the storage compartment. They are located on drivers side middle and the passengers side rear.**



- 2 Pull straight up to remove the shifter handle. This may stick and might take some force to remove.**



- 3** Remove the shifter bezel, you may need a flat tool to pry up. Watch for the light on the divers side that will need to be unplugged to remove the bezel. Now use the Phillips head screw driver to remove the screw in the lower right corner of shifter opening.



- 4** Remove the four wheel driver selector bezel, this may need a flat tool to pry up. Now use a Phillips head screw driver to remove the screw in the middle near the selector.



- 5** Moving to the back seat, you can now lift the center console up to see the broken stock center console bracket. You should be able to wedge the center console between the seats to hold it up.



- 6** Remove the three Phillips head screws holding the stock center console to the body. There is one in the front on the passenger side, one on the rear on the passenger side, and one on the rear drivers side. Remove the stock bracket and any broken pieces once it is free.



- 7** Place the new JcrOffroad center console bracket into place. Make sure that the side with one leg goes in facing forward, like the photo below. Start to thread all three mounting screws in before tightening them down.



- 8** Push the center console back down over the new bracket. Follow these instructions in reverse to reinstall the center console and bezels.

- 9** Enjoy your now secure center console!

**XJCC-97-PC - XJ CENTER CONSOLE BRACKET - CHEROKEE (97-01)**



**Item Code Legend**  
**EX: XJCC-97-PC**

**Additional Parts**  
**NONE**

**Bolt Pack:**  
**NONE**

**REVISED: 4/14/16**