



# JEEP CHEROKEE 50" LED BRACKET INSTALLTION INSTRUCTIONS

## TOOLS NEEDED

- 3/16 Allen Head Wrench

## HARDWARE

- 5/16 x 5/8 Button Head (4)
- 1/4 Washer (4)

**Please read the mounting instructions below  
carefully before attempting to install.**

Thank you for purchasing your new LED Bracket from JcrOffroad!  
Checkout our website, [www.jcroffroad.com](http://www.jcroffroad.com) for more deals and  
other great off-road products. Be sure to rate and review our prod-  
uct online. If you have any questions or are missing parts, please  
don't hesitate to call us at 269-353-1184!

**1** Make sure that the mounting location is clean and clear of debris.

**2** Place the LED Mount with the nuts facing out.



**3** Line the holes on the clamp up with the nuts on the LED Mount with the 90 degree bend under the gutter rail.

**4** Using a 3/16th Allen Head Wrench, screw in the included button head bolts/washers until they just touch the clamp for a loose fitting. Repeat on the opposite side.



**5** Place your light bar in either mounting slots on each side.



**6** Tighten the light bar mounting bolts.

**7** Tighten the clamp bolts.

Optionally, you could change the button head bolts to Security or Tamper Proof bolts as long as they are 5/16 x 5/8.