




JT

BEDSIDE MOLLE PANEL

INSTALL INSTRUCTIONS






Please read the mounting instructions below carefully before attempting to install.





Be sure to check out the install video on the product page, if available.

Thank you for purchasing from JcROffroad! Checkout our website, www.jcroffroad.com for other great off-road products. Be sure to rate and review our product online. If you have any questions or are missing parts, please don't hesitate to call us at 269-353-1184!

INCLUDED HARDWARE




INCLUDED PARTS




ASSEMBLY

- 1 Start by attaching the two MOLLE panels together using two 5/16"-18 X 3/4" bolts and 5/16"-18 serr. flange nuts. It doesn't matter which panel goes on top of the other, that is up to your preference. Just make sure that the front panel is flipped so that the JCR logo is legible for whichever side of the bed it is being installed on.



ASSEMBLY

- 2 Next, cut the piece of edge trim into two smaller pieces that will fit the bottom edge of the wider bracket and then put it on. Then, bolt both of those brackets to the inside of the panel in the positions shown below using the 5/16"-18 X 3/4" bolts and 5/16"-18 serr. flange nuts. Make sure that the bottom edge of the brackets are pointing towards the side of the bed.



ASSEMBLY

- 3** Next, mount the three other brackets to the side of the bed. If you have a Trail Rail, you will need to remove it so that you can mount the brackets between the Trail Rail and the bed using the same holes and factory hardware. If you do not have the Trail Rail, simply bolt the brackets into the holes that would be used for the Trail Rail using the M6 X 25mm Bolts and 1/4" washers. Leave the bolts somewhat loose for now
- 4** Once the brackets are in place, mount the MOLLE panel to them using the 5/16"-18 X 3/4" bolts and 5/16"-18 serr. flange nuts. The slots in the brackets should line up with the slots in the top of the panels.

